

# GENERAL INFORMATION

1

## CONTENTS

<b>WARNING/CAUTION/NOTE</b> .....	1- 2
<b>GENERAL PRECAUTIONS</b> .....	1- 2
<b>SUZUKI LT-R450K6 ('06-MODEL)</b> .....	1- 4
<b>SERIAL NUMBER LOCATION</b> .....	1- 4
<b>FUEL, OIL AND ENGINE COOLANT RECOMMENDATION</b> .....	1- 5
<b>FUEL (FOR USA AND CANADA)</b> .....	1- 5
<b>FUEL (FOR OTHER COUNTRIES)</b> .....	1- 5
<b>ENGINE OIL (FOR USA)</b> .....	1- 5
<b>ENGINE OIL (FOR OTHER COUNTRIES)</b> .....	1- 5
<b>BRAKE FLUID</b> .....	1- 5
<b>ENGINE COOLANT</b> .....	1- 6
<b>BREAK-IN PROCEDURES</b> .....	1- 6
<b>INFORMATION LABELS</b> .....	1- 7
<b>SPECIFICATIONS</b> .....	1- 8
<b>DIMENSIONS AND DRY MASS</b> .....	1- 8
<b>ENGINE</b> .....	1- 8
<b>DRIVE TRAIN</b> .....	1- 8
<b>CHASSIS</b> .....	1- 9
<b>ELECTRICAL</b> .....	1- 9
<b>CAPACITIES</b> .....	1- 9

## COUNTRY AND AREA CODES

The following codes stand for the applicable country(-ies) and area(-s).

CODE	COUNTRY or AREA	EFFECTIVE FRAME NO.
E-19	E.U.	JSAAL41A 62100001 –
E-28	Canada	JSAAL41A 62100001 –
E-33	California (U.S.A.)	JSAAL41A 62100001 –