


GENERAL INFORMATION




(1) The frame serial number is stamped on the right side of the steering head.




(2) The engine serial number is stamped on the right side of the upper crankcase.



(3) The Vehicle Identification Number (VIN) is located on left side of the main frame on the Safety Certification Labels.



(4) The throttle body identification number is stamped on the intake side of the throttle body as shown.



(5) The color label is attached as shown. When ordering color-coded parts, always specify the designated color code.

1-2 Download this Manual