



Lubrication

Lubricate the following areas every 60 days for fresh water use or every 30 days for salt water use.




1111




2222


HBF2



DR28241




DR4182




DR30079


BHL2T, BHL4T, BF2T, BF4P, BFL4P, BFLX4P, BF4TP, BFL4TP, BFX4TP



DR29085



DR15790



DR14971