

# SECTION 1 — GENERAL INFORMATION

---

---

## TABLE OF CONTENTS

---

---

General Specifications .....	1-2
Snowmobile Identification .....	1-2
Recommended Gasoline and Oil .....	1-2
Break-In Procedure .....	1-3
Genuine Parts .....	1-3
High Altitude Operation (660 cc/1100 cc Z1) .....	1-3
Drive Chain Lubrication (120 cc Model) .....	1-3
Tipped Snowmobile (660 cc Models) .....	1-4
Low Oil Pressure Warning Light (660 cc/ 1100 cc Z1 Models) .....	1-4
Check Engine Light (660 cc/1100 cc Z1 Models)....	1-5
Diagnostic Codes/Check Engine (660 cc Models) ..	1-5
Diagnostic Codes/Check Engine (1100 cc Z1).....	1-5
Chassis Control Unit (1100 cc Z1) .....	1-6
Diagnostic Codes/Chassis Control Unit (1100 cc Z1).....	1-6
Preparation For Storage .....	1-6
Preparation After Storage .....	1-7
After Break-In Checkup (500 Miles) .....	1-8
After Break-In Checkup Checklist .....	1-9
Torque Conversions .....	1-10
Tightening Torque (General Bolts) .....	1-10
Fraction/Decimal Conversion Chart .....	1-11
Drill Bit Sizes (Number) Chart .....	1-11
MM/In. Conversion Chart .....	1-12