

TABLE OF CONTENTS

SECTION	SUBSECTION	PAGE
SAFETY NOTICE		III
WHAT'S NEW		IV
INTRODUCTION		V
01	SERVICE TOOLS AND SERVICE PRODUCTS	
	01 – Service tools.....	01-01-1
	02 – Service products.....	01-02-1
02	LUBRICATION AND MAINTENANCE	
	01 – Periodic maintenance chart.....	02-01-1
03	TROUBLESHOOTING	
	01 – Table of contents.....	03-01-1
	02 – Engine	03-02-1
	03 – Fuel and oil systems.....	03-03-1
	04 – Transmission and brake systems.....	03-04-1
	05 – Electrical system	03-05-1
	06 – Suspension and track	03-06-1
04	ENGINE	
	01 – Table of contents.....	04-01-1
	02 – 493, 593, 693 and 793 engine types.....	04-02-1
	03 – Leak test and engine dimension measurement.....	04-03-1
	04 – CDI system.....	04-04-1
	05 – Oil injection system.....	04-05-1
	06 – Liquid cooling system.....	04-06-1
	07 – Rewind starter.....	04-07-1
	08 – Carburetor and fuel pump	04-08-1
	09 – Fuel tank and throttle cable.....	04-09-1
05	TRANSMISSION	
	01 – Table of contents.....	05-01-1
	02 – Drive belt.....	05-02-1
	03 – Drive pulley.....	05-03-1
	04 – Driven pulley.....	05-04-1
	05 – Pulley distance and alignment.....	05-05-1
	06 – Brake	05-06-1
	07 – Chaincase	05-07-1
	08 – Gearbox	05-08-1
	09 – Drive chain.....	05-09-1
06	ELECTRICAL	
	01 – Table of contents.....	06-01-1
	02 – Ignition timing.....	06-02-1
	03 – Spark plugs.....	06-03-1
	04 – Battery.....	06-04-1
	05 – Electric starter	06-05-1
	06 – Testing procedure	06-06-1
07	REAR SUSPENSION	
	01 – Table of contents.....	07-01-1
	02 – SC-10 II suspension.....	07-02-1
	03 – SC-10 Mountain suspension	07-03-1
	04 – Drive axle.....	07-04-1
	05 – Track.....	07-05-1